

Wall Hanging Electric Suite

Easy Fitting Instructions



Helpful Advice Before Fitting

1. These instructions are provided in an easy to follow style. Simply follow the instructions in sequence to fit this product.
2. Please retain all packaging until you have checked and counted all the parts and the contents of the fixing pack against the parts list.
3. The fixing pack contains small items, which should be kept away from young children. We suggest that you open the fixing pack and place all the contents into a container, therefore reducing the risk of losing any small pieces.
4. To clean your surround, we recommend that you use a glass cleaner, do not use other abrasive cleaners as these could damage the finish. Use baby oil or WD-40 to clean the brushed stainless steel fire.

In the unlikely event that this product has missing parts or damaged parts, please call our help-line on **0845 224 2811** for assistance, or to obtain spare parts.

Tool List:

- An electric drill (We recommend that you secure the unit to the wall using the fixing pack supplied)
- Phillips screwdriver
- Pencil
- Spirit level

Parts List

Please ensure that you have all the correct parts before beginning to fit this suite.

- Electric suite
- Pebble pack
- Wall hanging template
- Wall fixing pack, containing:
 - 2 x Wall plugs
 - 32mm Screws x 2

Important notes prior to fitting

- DO NOT use this appliance in the immediate vicinity of a bath, shower or swimming pool.
- DO NOT allow the heater unit to be covered as this may cause overheating.
- This appliance is supplied with a pre-wired 3-pin plug (13 AMP fuse rated) and electric cable. It is therefore necessary that a suitable electric socket is nearby and easily accessible.
- The bulb should only be changed when the suite has been switched off and has been allowed to cool down.
- The buyer should not attempt any repairs to the heater unit. In the event of a fault, return the suite to where it was purchased.
- The product has electrical components, before working on or near any part of the light housing, isolate it from the mains by unplugging the suite.
- There are no specific requirements for the care of this unit, other than general cleaning. The surround must be cleaned using glass cleaner. DO NOT use abrasive cleaners as they may damage the finish. We recommend that baby oil or WD-40 is used to clean the stainless steel fire.

Fitting Instructions

Your electric suite is supplied fully assembled. To fit the product to the wall, simply follow the instructions below:

- Using the wall hanging template provided, position it on to the wall to the desired height and mark holes (the top of the surround is 90mm above the mounting holes)

Use the spirit level to make sure the template is level, then mark through the holes with a pen or pencil. (*Figure 1*)



Figure 1

- Drill holes into the wall using a 6mm bit and insert wall plugs. Obtain the screws and secure into the plug leaving approximately 5mm unscrewed.

Obtain the product, align with the key-holes at the back of the fire and simply hang on to the screws!
(Figure 2)



Figure 2

Assembling the Fuel bed

Remove the loose pebbles from their packaging. Place the larger pebbles down the front of the bars, then randomly place the remaining pebbles on top of the bed.

Changing the Bulb

Please ensure that the suite is disconnected from the mains before attempting to change the bulb.

- Remove the pebbles from the fuel bed
- Remove the magnetised trim from the fire
- Unscrew the 4 screws attaching the fret to the fire as shown in *figure 3*
- Remove the single screw attaching the plastic pebble bed to the fire as shown in *figure 4*
- Remove the plastic pebble bed
- Unscrew the existing bulb and replace with a 40watt (max) BC bulb as shown in *figure 5*
- Replace the plastic pebble bed, the fret and the trim, then reassemble the fuel bed with the pebbles.
- Reconnect to the mains and the suite is ready to use!




Figure 3





Figure 4



Figure 5

Appliance Data

- Supply Voltage; 230/240 Vac, 50H
- Heating Elements: 2 x 961W max
- Fuse Rating: 13 AMP
- Lighting 1 x 40 BC Bulb (max)



Operating the Suite

The appliance is controlled using 4 switches, mounted under the hood of the fire. The left switch (OI) controls the main power to the fire and switches on the glow effect which can be used independently for visual effect only.

The second switch (Fan) operates the fan blower without heat, which can be used in the summer for cool air circulation. The switch marked with a single bar (I) operates the fan heater to the low setting (1KW). The switch marked with two bars (II) operates the fan heater on the high setting (2KW)

All 4 switches need to be depressed to operate the 2KW setting

Safety Cut-Out System

This appliance has a safety cut out system fitted, which will activate if the air inlets or outlets are obstructed. For safety reasons, the fire will NOT switch back on again automatically. The following procedure must be carried out before the heater can operate again.

- Switch off the appliance at the wall socket outlet; leave the heater off for a period of time of no less than 10 minutes ensuring that all obstructions are removed. Switch the appliance back on at the wall; ensure that the appliance is turned on at the control switches.
- If the heater fails to operate correctly, repeat the above procedure. If an attempt to switch on the appliance, before the safety cut out has reset, the appliance may cut out for a further period of time.
- If this sequence has been followed correctly and the appliance still fails to operate, check the fuse in the wall outlet. If this has not blown, Call an electrician or maintenance engineer.

Please Note – If you need any further advice or spare parts for this suite, please contact our customer help-line on the details below. This product has a 1 year manufacturers guarantee.



Customer telephone helpline: 0870 244 2811
Helpline email address: helpline@adamsurrounds.co.uk