

# AURORA

## DOWN LIGHT INSTALLATION & BULB REPLACEMENT

### IMPORTANT INSTRUCTIONS

#### DO'S

- Read ALL the instructions before installing the Down Light set.
- Only use this Down Light set for its intended use as described in this manual.
- Always install the Down Light set in accordance with this guide. If in doubt obtain expert advice.
- Always make sure the electrical socket is accessible after installation.
- Always disconnect the Down Light set from the electrical supply before carrying out cleaning or maintenance.

#### DON'TS

- Never route the mains supply cord under carpet etc.
- Never use the Down Lights if the supply cord or plug is damaged or if the Down Lights have been damaged in any manner.
- Never allow the supply cord to touch hot surfaces.
- Never use aerosols or steam cleaners on or around the Down Lights.

Any new wiring required, must be in accordance with local and national codes and other applicable regulations in order to reduce the risk of fire, electric shock, or other injuries

Check the Down Lights and the supply cord for damage regularly.


If the supply cord becomes damaged, it must be replaced by a suitably qualified person using the same rated cable. Do not attempt to make repairs to the transformer.

When cleaning, or replacing the bulbs, always pull out the plug from the socket outlet. Never yank the cord to disconnect from the outlet, instead grasp the plug and pull to disconnect.


### SAVE THESE INSTRUCTIONS

## INSTALLATION

Ensure the downlights are not connected to a mains supply before installation




1. Remove the power cable and transformer from packaging. Check for any connections that may have come loose during transit




2. Thread the wire through the surround and out through a natural opening around the hearth of the product. The plug **MUST** be accessible

**WARNING:** Ensure the supply cord exits the surround without being damaged.


The supply cord must be secured to prevent it from being pulled or snagged once the installation has been completed.



3. Take the bulb holder and squeeze the spring clips together. Insert the holder into the cut out, ensuring any wires pass through the centre



4. Gently insert bulb into light fitting, be careful not to use excessive force as this may damage the fitting



5. Squeeze the ends of the circclip together to insert it into the bulb holder. This will secure the bulb

## USE

To activate the down lights, insert plug into mains power source. To deactivate, un-plug from mains power source.

## REPLACING THE BULB

1. Switch product off from mains supply. CAUTION: Bulbs get hot during use, allow to cool before attempting to remove
2. Remove the circlip by squeezing tabs together to release bulb.
3. Remove the old bulb - the bulb is push-fit
4. Using a soft cloth, fit the new bulb. CAUTION: Use the same type of bulb as stated in the Appliance Data section of the product's instructions.

## CARE

- Always switch off and allow the bulb to cool before attempting to replace bulbs.
- Always switch off or disconnect from the mains supply when cleaning the product.
- Wipe clean with a soft dry cloth. Never use scourers, abrasives, or chemical cleaners.
- Do not allow moisture to come in contact with electric parts.

## APPLIANCE DATA

- Supply voltage: 220-240V~, 50Hz
- Type of Bulb: MR11 12V 20W GU4

## CONFORMITY WITH DIRECTIVES

Conforms with relevant European Directives

## ENVIRONMENTAL PROTECTION

- (WEEE) Waste Electrical and Electric Equipment

Waste electric products should not be disposed of with household waste.  
Please recycle where facilities exist. Check with your Local Authority or retailer for recycling advice.



[www.aurora-marble.com](http://www.aurora-marble.com)



[www.firedupgroup.co.uk](http://www.firedupgroup.co.uk)

Fired Up Corporation Ltd.  
Fired Up Buildings  
St Thomas Road  
Huddersfield  
HD1 3LF  
United Kingdom