

|                      |               |
|----------------------|---------------|
| Model Number         | ND-189        |
| Supply Voltage/Freq. | 220-240V~50Hz |
| Rated Power          | 2000W         |

## IMPORTANT SAFETY CAUTIONS

- Follow these precautions to reduce the risk of fire, electric shock, and injury.
- Use this heater on an AC supply only, and ensure the voltage matches the rating on the heater.

### DO'S


- Keep furniture, curtains, and other flammable materials at least 1 meter away.
- For household use only; not suitable for industrial use.
- Regularly inspect the cord. Do not use the appliance if the plug, cord, or unit is damaged.
- Any repairs must be carried out by a qualified electrician.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent, or a qualified person.
- Use only accessories recommended by the manufacturer.
- This appliance must not be used by persons with reduced capabilities or by children without proper supervision or instruction.
- Children under 3 years must be kept away.
- Children aged 3–8 may only switch the appliance on/off under supervision and must not plug in, adjust, or clean it.
- Children over 8 and persons with reduced capabilities may use the appliance if supervised and instructed on safety.
- Children must not play with the appliance.

### DONT'S

- Do not switch on the appliance until it is properly installed as described in the manual.
- Do not place the heater directly below a socket outlet.
- Do not leave the appliance unattended while in use or connected to the mains.
- Do not run the mains cable under carpets or rugs, or allow it to touch sharp edges or hot surfaces.
- **WARNING:** Do not cover or obstruct the heater to avoid overheating.
- Never immerse the heater in water or use it near baths, showers, or swimming pools.
- Do not use outdoors or with wet hands.
- Do not place the appliance on or near hot surfaces.
- **CAUTION:** Some parts may become very hot.
- Do not lift the appliance by the front panel.
- **CAUTION:** Do not supply the heater through an external switching device (e.g., timer) or a circuit that is regularly switched on/off.
- **WARNING:** This heater does not control room temperature.
- Do not use the heater in small rooms occupied by persons unable to leave unless constant supervision is provided.

### CLEANING AND MAINTENANCE

- This product does not use a standard bulb for its flame effect. The appliance uses an electronically controlled LED system to create the flame effect; therefore, no parts need to be replaced.
- **WARNING:** Always disconnect the heater from the power supply before cleaning.
- For general cleaning, use a soft, clean duster—never use abrasive cleaners. The glass viewing screen should be cleaned carefully with a soft cloth. Do NOT use proprietary glass cleaners.



## THERMOSTAT

The Thermostat is designed to maintain a comfortable room temperature

To set, switch the heat on and turn the THERMOSTAT to MAX. When the desired temperature is reached, slowly turn the THERMOSTAT towards

LOW until the heat turns off.

Please note that the appliance can only be switched on when the thermostat

## SAFETY CUT-OFF

- This appliance is fitted with a safety cut-off which will operate if the fire overheats (e.g. Due to blocked air vents). For safety reasons, the fire will NOT automatically reset.
- To reset the appliance, disconnect the appliance from the mains supply for at least 15 minutes. Reconnect the supply to the mains and switch on the appliance.

## TECHNICAL PARAMETERS

|   |               |       |      |  |      |
|---|---------------|-------|------|--|------|
| Model identifier(s):                                    | <b>ND-189</b> |       |      |  |      |
| Item  | Symbol        | Value | Unit | Item   | Unit |
| <b>Heat output</b>                                      |               |       |      | <b>Type of heat input, for electric storage local space heaters only</b> |      |
| Nominal heat output                                     | $P_{nom}$     | 2.0   | kW   | Single stage heat output and no room temperature control                 | no   |
| Minimum heat output (indicative)                        | $P_{min}$     | 1.0   | kW   | Two or more manual stages, no room temperature control                   | no   |
| Maximum continuous heat output                          | $P_{max,c}$   | 2.0   | kW   | With mechanic thermostat room temperature control                        | yes  |
| <b>Power Consumption</b>                                |               |       |      | With electronic room temperature control                                 | no   |
| In off mode   | $P_o$         | 0.0   | W    | Electronic room temperature control plus day timer                       | no   |
| In standby mode   | $P_{sm}$      | N/A   | W    | Electronic room temperature control plus week timer                      | no   |
| In idle mode  | $P_{idle}$    | N/A   | W    | <b>Other control options (multiple selections possible)</b>              |      |
| In network standby                                      | $P_{rsm}$     | N/A   | W    | Room temperature control, with presence detection                        | no   |
| Standby mode with display of information or status      |               |       | no   | Room temperature control, with open window detection                     | no   |
| Seasonal space heating energy efficiency in active mode | $\eta_{s,on}$ | 85    | %    | With distance control option   | no   |
|   |               |       |      | With adaptive start control  | no   |
|   |               |       |      | With working time limitation   |      |
|   |               |       |      | With black bulb sensor   | no   |
|   |               |       |      | Self-learning functionality  | no   |
|   |               |       |      | Control Accuracy   | no   |

## ENVIRONMENTAL PROTECTION

For electrical products sold within the European Community.



EN

This appliance is labeled in accordance with European Directive 2002/96/EC concerning Waste Electrical and Electronic Equipment (WEEE). Waste electrical products should not be disposed of with household waste. Please recycle where facilities exist. Check with your Local Authority or retailer for recycling advice.

## GUARANTEE

Please ensure that you retain your receipt which will act as both proof of purchase and a guarantee validation document.

Your product carries a 1 year guarantee from the date that the original purchaser receives it. If your product fails within the guarantee period please ensure that you have all necessary documentation available including proof of purchase (receipt or invoice with serial number, location and date of purchase) in addition to all original undamaged packaging and leaflets etc. It is strongly recommended that you inspect your product carefully before it is used or installed.

This product guarantee does not affect your statutory rights.



 03300 882 069

 [www.firedupcorporation.com](http://www.firedupcorporation.com)

 [customer.support@firedupcorporation.com](mailto:customer.support@firedupcorporation.com)

**Fired Up Corporation Ltd**

**UK:** HD1 3LF

**EU:** 71, D02 P593, Dublin

**CN:** Nantou, 528427, Zhongshan